

Preparations:

IMPORTANT! IMPLEMENT ALL OF THE FOLLOWING!

1. Remove the factory storage grease with a grease remover.
2. Carefully wash the hull with a boat shampoo (without wax) and rinse with water.
3. Carefully grind the surface with abrasive paper (grit 60).
4. Remove any loose dust/powder.

Product (Hempel)	Layers	Recoating time at 20 °C	Spreading rate	Thinner
Light Primer weakened 25 %	1	4 hrs – 30 days	13	845
Light Primer	1	4 hrs – 30 days	8,5	845
Yacht Primer	1	min. 3 hrs	9,5	823
Aludafe Antifouling	2-3	min. 9 tim	13	808

Recoating times only apply when recoating with the same product in a +20 °C temperature.

The products shown here are only exemplary.

Painting measurements	A/cm (from bow loop)	B/cm (inflection point)	C/cm (stern)
Silver Colibri	40	185	13
Silver Beaver	40	240	15
Silver Fox (->2017)	40	190	11,8
Silver Wolf	39	275	8
Silver Hawk	40	220	9,8
Silver Shark	60	200	9,7
Silver Shark BRX	60	200	9,7
Silver Eagle BR	56	301	15
Silver Eagle BRX	56	301	15
Silver Eagle CC	50	190	7
Silver Eagle DC	50	190	11
Silver Eagle Cabin	50	250	11
Silver Star Cabin	50	250	11
Silver Eagle WA	50	250	11
Silver Moreno	45	360	12,4
Silver Condor	47	370	5,7

The measurements are approximate, as they highly depend on which engine is mounted on the boat. If the largest possible engine is installed on the boat or/and the boat otherwise has a high weight load, the painting measures (paint line) should be moved upwards.

ANTIFOULING MEASUREMENTS

